Abstract

Utilizing the Linux bash shell to create, remove and manage users, groups, and directories as well as using commands to write into files. Learning how file and directory permissions are used and changed for groups and users.


Introduction

The Linux command line in the bash shell will be used to create users, groups, and directories. Users will be placed into groups with specific permissions given. A directory named CS497, and a file called the myFile.txt will be created and managed with the bash shell. Permissions will be checked using the command 'ls -la'. The 'cat' command will be used to create and write into the myFile.txt. Commands such as 'date', 'uname -a', 'whoami', and 'ip address' will be redirected into the myFile.txt using the '>' operator. Permissions to different groups will be changed, and information retrieval commands will be used on the myFile.txt.

Summary of Results


On the Linux terminal two groups will be created using the command: sudo groupadd [groupName]

```
sudo (for root privileges) groupadd (create a group)
```




Two users will be created using the command: sudo useradd [username]

```
sudo (for root privileges )
useradd (create a group )
```



To add the users into a specified group, use the command: sudo usermod -g [groupname] [username]

```
usermod ( make changes to an existing user )
-g ( change the primary group for a user)
```




Change the directory location to /var/tmp with the command: cd /var/tmp

Create a directory with the command: mkdir [directory name]


Check the permissions to the directory using the command: ls -la

```
cd (change the directory)
mkdir (make a directory)
ls (list files)
ls -la (detailed info on every file)
```



Within this new directory, a text file will be created, named myFile.txt using the command: cat > [filename]


```
cat ( print content of a file )
cat < ( write to a file)
```



The following commands will be used in order to redirect the output into the new text file:

```
date > [filename] (retrieves the date )
uname -a > [filename] (retrieves the kernel version )
whoami > [filename] (retrieves username )
ip address > [filename] (retrieves the ip address )
```


To show the contents of the file, use the command: cat [filename]




Change the directory by using the command: cd [directory location]

Move the directory to another location using the command: mv [directory] [new directory location]

```
cd (change directory )
mv (move )
```




The moved directory (named CS497) is now at its new location.



To confirm that the directory does not exist in its previous location, an attempt to access the directory will be done with the command: cd [directory location]

The directory does no longer exist.




The permissions for the 'CS497' directory and the myFile.txt file, now located on the desktop will be checked with the command:

ls -la

To read the permissions, one must know:


```
d (directory permission )
- (when at the start) (file permission )
r (read permission )
w (write permission )
x (execute permission )
- (no permission )
```

[directory/file][rwx for user][rwx for group][rwx for others]




The command to specifically look at a files permissions is:

ls -l [filename]



To make the user account into the owner of a directory, use the command: chown [useraccount] [directory]

chown (change owner)



A way to have certain groups have specific permissions to directories and files, change the ownership to the group, then change the permissions allowed for the group with the command: sudo chown [original owner]:[new owner] [directory/file]


To change the owner permissions to read-only, use the command: chmod o=r [directory name]

To change the owner permissions to read and write, use the command: chmod o=rw [directory name]

chmod (change the access permissions)

To display the word count of a file, use the command: wc -w [file name]

wc (word count)



Conclusion

The bash shell in Linux can be used to create, remove, and manage user groups, and directories, along with writing into files, and creating specific permissions for users, groups and others. To access the man page for the 'chmod', use the command:

man chmod

To change the permissions for a file to be readable and writable for the owner, but only readable to the group and others, use the command:

chmod 644 [filename]

Permissions 644 represent '-rw-r--r-', by following the values:

read = 4 write = 2 execute = 1

Other numbers would represent different permissions, such as 666 would be -rw-rwrw-. To make a file only readable by a user, the permissions would be '-r----- 'which is chmod 400. To make files executable, the x's are needed for the permissions such as '-rwxrwxrwx' for example, which gives full permissions, thus being chmod 777. Access permissions can only be changed by the root user and the owner of the file.

